





51 1422/00
EU1, F1, GB1
Gebrauchsanweisung
(D, GB, F, I, NL, E)



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss				
Typ/Type		TL 4 A				
Förderleistung/Delivery/Débit		l/h	702			
Anlaufstrom/Starting current/Cour. de démarrage		A	7,8			
Widerstand/Resistance/Résistance		Ha/main/prin.	23,8			
		Hi/aux	17,0			
Temp. Regler/Thermostat		M + J				
Typ/Type		TF 57				
Reglerstellung/Position		kalt warm				
Schaltwerte/Switching values/ Valeurs de commutation		„ein“	+ 4			
		„aus“	- 30			
(„abtauen“ od.)		„alarm“	- 15			
Füllmenge/Fill.quantity/Charge		R12	g	120		
Anschlußwert/Conn.load/Puiss. connectée			W	110		
Heizung/Heater/Chauffage						
Widerstand/Resistance/Résistance			Ω			
Leistung/Power/Puissance			W			
Ventilator/Blower/Ventilateur						
Widerstand/Resistance/Résistance			Ω			
Magnetventil/Magnetic valve/Electrovanne						
Widerstand/Resistance/Résistance			Ω			
Spannung/Voltage/Tension			V			

Pos.	EU1, F1,GB1			
	Danfoss			
1	13 1064/45			
2				
3	02 0108/27			
4				
5	02 1361/04			
6	05 1413/06			
7				
8	11 0437/04			
9	05 0166/05/4			
10				
11	11 1243/01			
12				
13				
14				