


**BOSCH**

GIL 130 – 0 705 134 214–D1
 – 0 705 134 215–CH1
 – 0 705 134 216–F1
 – 0 705 134 222–SF1

GEFRIERGERÄTE
 Gefrierschränke, Einbau

Ident – Nummern – Konstante
 3740




51 0384/00
 D1, CH1, F1, SF1
 Aufstellanleitung
 (D, GB, F, I, NL, DK, S, SF, E)
 51 1734/00
 D1, CH1, F1, SF1
 Gebrauchsanweisung
 (D, GB, F, I, NL, DK, S, SF, E)

**BOSCH**

GIL 130 – 0 705 134 214–D1
 – 0 705 134 215–CH1
 – 0 705 134 216–F1
 – 0 705 134 222–SF1

GEFRIERGERÄTE
 Gefrierschränke, Einbau

Ident – Nummern – Konstante
 3740



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss				
Typ/Type		TL 5 A				
Förderleistung/Delivery/Débit		l/h	V 920			
Anlaufstrom/Starting current/Cour. de démarrage		A	9,0			
Widerstand/Resistance/Résistance		Ha/main/prin.	Ω	15,7		
		Hi/aux	Ω	18,8		
Temp.-Regler/Thermostat		M + J				
Typ/Type		TF 57 SF				
Reglerstellung/Position			kalt	warm		
Schaltwerte/Switching values/ Valeurs de commutation		„ein“	- 28	- 19		
		„aus“	- 34	- 26		
		(„abtauen“ od.)	„alarm“	- 20	- 15	
Füllmenge/Fill.quantity/Charge		R12	g	90		
Anschlußwert/Conn.load/Puiss. connectée			W	120		
Heizung/Heater/Chauffage						
Widerstand/Resistance/Résistance			Ω			
Leistung/Power/Puissance			W			
Ventilator/Blower/Ventilateur						
Widerstand/Resistance/Résistance			Ω			
Magnetventil/Magnetic valve/Electrovanne						
Widerstand/Resistance/Résistance			Ω			
Spannung/Voltage/Tension			V			

Pos.				
	Danfoss			
1	14 0085/45			
2				
3	02 0108/27			
4				
5				
6	05 1413/05			
7				
8	11 0437/04			
9	05 0166/05			
10				
11				
12				
13				
14				