




Gebrauchsanweisung
58 6604
(en)


Kochbuch
58 5154
(en)


Zubehör:

Dampfgarer
N8640X2

Backblech, Alu
Z1330X0
Backblech Email
Z1340X2
Brotbackstein
Z1910X0
Nachrüstsatz Clou4/Kat.
Z1750X0
Auflaufform
Z1270X2
Grillset klein
Z1240X2


1) 16 8588





- 1) 02 6593
- 2) 17 2643
- 3) 18 3938
- 4) 17 2895
- 5) 17 2646
- 6) 17 2765
- 7) 35 5648

V01
17 2958
V02
35 5678
V02



- 1) 48 3856
kompl.
- 2) 41 8562
- 3) 17 1146