






Libro de instrucciones
51 8146
(D,GB,F,E,I,P)





Pos.	ASPERA	ZEM
	B1116Z	GL80AB
1	14 1599	14 1599
2	16 1628	15 4890
3	16 1631	15 4887
4	16 1633	09 6836
5	35 0684	35 0684
6	15 4915	15 4915
7	05 0166	05 0166
8		
9		
10		
11		
12		
13		

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor	ASPERA	ZEM
Typ/Type/Tipo	B1116Z	GL80AB
Förderleistung/Delivery/Debit/Aspiración l/h		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		
Hi/aux.		

Temp.Reyler/Thermostat/Termostato	RANCO	
Typ/Type/Tipo	K54–L1936	
Reglerstellung/Position/Conexión		
Schaltwerte/Switching values/	..ein/conex.°C	MIN. MAX.
Valeurs de commutation/Desconex.	..aus"/descon.	–17° –23,5°
(..abtaven' od)	..alarm'	— –29°

Füllmenge/Fill. quantily/Charge/Carga R134a	g	*	*
---	---	---	---

Anschlußwert/Comm. load/puiss. Connect./Potenc.	W		
---	---	--	--

Heizung/Heater/Chaufrage/Resistenc.descong.			
Widerstand/Resistance/Resistencia	Ohm		
Leistung/Power/Puissance/Potencia	W		

Ventilador/Blower/Ventilateur/Ventilador			
Widerstand/Resistance/Resistencia	Ohm		

Magnetventil/Magnetic valve/Electrovanne/Electrovalvula			
Widerstand/Resistance/Resistencia	Ohm		
Spannung/Volare/Tension/Tensión	V		

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador			
---	--	--	--

* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características