



Ident.-Nummern-Konstante
3740





51 1553
EU1
Gebrauchsanweisung
D,GB,T,I,NL
51 2277
Aufstellanleitung
1) 04 2085
Set
2) 04 2105
Set
3) 01 9177
Set

Ident-Nummern-Konstante
3740

- 1) 08 0781
Set
- 2) 02 5067
Set
- 3) 01 9204
Set
- 4) 05 1838
bis FD 6504
- 5) 05 5117
ab FD 6505
- 6) 14 0338
220 V 50 Hz
05 5114
5 μ F
bis FD 6504
- 7) 14 0339
220 V 50 Hz
02 7377
Relais
ab FD 6505

Ident-Nummern-Konstante
3740



Ident-Nummern-Konstante
3740

- 1) 08 2970
Set
- 2) 08 2971
Set
- 3) 04 3889

Ident-Nummern-Konstante
3740

1) 01 9202

2) 11 0668
Set

3) 05 1287
Set

