

**BOSCH**


BOSCH T 445 – 0 728 144 106–D1
– 0 728 144 107–GB1
– 0 728 144 108–CH1


WASCHGERÄTE
Trockner


Ident-Nummern-Konstante
3740

Aufstellanweisung
51 0805
(D, I, F, NL, GB,
S, DK, N, SF)

Gebrauchsanweisung
51 1818
(D, I, F, NL, GB,
S, DK, N, SF)







1) 14 0093

