





ex20396 -4/1


Instrucciones de uso
58 2667
(es)
58 2668
(pt)
58 0576
(en,fr,de)
58 0577
(ca,eu,ga)

Tabla de programas
41 6485
(es)
41 6486
(pt)


1) 36 3356

Tapa metálica – VDE
21 5174





1) 26 5964



	ASKOLL	COPRECI
1	17 2340	17 2337
2	15 1408	15 4358
3	15 1409	17 2339
4		
5		