


BK5000/02-V01
BK5000C/02-V02
BK5000DBY/01-V10
BK50001/02-V09


BK5000SU/02-V03
BK5200D/02-V04
BK5200DSU/02-V05
BK52000/02-V06

BK52000CH/02-V07
BK53000/02-V08



Gebrauchsanweisungen
51 3654
(D,F,T,NL)
V01
51 4827
V03
51 5353
(D,F,I,NL,GB)
V04,V06...V08
51 6538
(D,GB,F,I,NL)
V09
51 7721
(D,GB,RUF,PL,HUN)
V10

Zubehör:
03 0103



Armatur kompl.
11 9613
V01...V08
11 9610
V09,V10