





Ident – Nummern – Konstante
3740

Gebrauchsanweisung
53 5772

- 1) 42 4357
- 2) 41 8066
- 3) 26 7356
- 4) 26 7357
- 5) 26 7359
- 6) 18 8756
- 7) 36 9869
- 8) 41 8881
- 9) 41 8694
- 10) 41 8696
- 11) 18 8268



Ident - Nummern - Konstante
3740

- 1) 16 9339
- 2) 17 3894
- 3) 17 3895
- 4) 49 4151
- 5) 48 8987-V01,V02
64 6489-V03
- 6) 48 8988-V01,V02
64 6490-V03
- 7) 48 8986-V01,V02
64 6488-V03

Duesensatz Für:
EG LL G25 25mbar
17 5527

FG G30/31 30mbar
17 4048

EG LL G25 25mbar
(inkl.Bypassduesen)
41 8134

FG G30/31 30mbar
(inkl.Bypassduesen)
41 7837