




Ident – Nummern – Konstante
3740

Gebrauchsanweisung
52 5678


V01,V02,V03,V04
V05,V06,V07
53 7549
V08

1) 17 3891
V01,V02
42 4423
V03,V04,V05,V06
V07,V08

- 2) 41 8119
- 3) 26 7356
- 4) 26 7357
- 5) 26 7359
- 6) 17 0664
- 7) 36 2414
- 8) 18 3762

49 4154
V01,V02
V03,V04
V05,V06
49 9591
V07,V08

26 8134



Ident - Nummern - Konstante
 3740

- 1) 16 9339
- 2) 48 4339
- V01
- 48 9635
- V02,V03
- 49 4151
- V04,V05,V06,V07
- V08

Duesensatz Für:
 EG H/E G20 20mbar
 17 4049

FG G30/31 30mbar
 17 4048

EG H/E G20 20mbar
 (inkl.Bypassdusen)
 41 7597

FG G30/31 30mbar
 (inkl.Bypassdusen)
 41 7837