







07 4445  
V01  
09 6325  
V02



Gebrauchsanweisung  
59 0242  
(de,en,it,nl)

Montageanleitung  
58 8057  
Beistellsatz  
26 5163





| Pos. | Danfoss |  |  |
|------|---------|--|--|
|      | TLY4K   |  |  |
| 1    | 14 2057 |  |  |
| 2    |         |  |  |
| 3    | 15 1055 |  |  |
| 4    |         |  |  |
| 5    | 15 0760 |  |  |
| 6    | 15 1072 |  |  |
| 7    | 16 9319 |  |  |
| 8    | 26 4879 |  |  |
| 9    | 050166  |  |  |
| 10   | 16 5852 |  |  |
| 11   | 36 5099 |  |  |
| 12   | 05 6008 |  |  |

| TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES |         |         |       |
|--------------------------------------------------------|---------|---------|-------|
| Verdichter/Compressor/Compresseur                      |         | Danfoss |       |
| Typ/Type                                               |         | TLY4K   |       |
| Förderleistung/Delivery/Débit                          | l/h     | 698     |       |
| Anlaufstrom/Starting current/Cour de démarrage         | A       | 5,9     |       |
| Widerstand/Resistance/Résistance                       | W       | 49,0    |       |
|                                                        | Hi/aux  | 15,0    |       |
| Temp.-Regler/Thermostat                                |         | Ranco   |       |
| Typ/Type                                               |         | K59     |       |
| Regelstellung/Position                                 |         | kalt    | warm  |
| Schaltwerte/Switching values                           | "warm"  | +5,0    | +5,0  |
| Valeurs de commutation                                 | "kalt"  | -25,0   | -10,0 |
|                                                        | "alarm" |         |       |
| Füllmenge/Fill.quantity/Charge                         | R600a   | +       |       |
| Anschlußwert/Conn.load/Puiss. connectée                | W       | 45      |       |
| Heizung/Heater/Chauffage                               |         |         |       |
| Widerstand/Resistance/Résistance                       | W       |         |       |
| Leistung/Power/Puissance                               | W       |         |       |
| Ventilator/Blower/Ventilateur                          |         |         |       |
| Widerstand/Resistance/Résistance                       | W       |         |       |
| Temp.-Regler/Thermostat                                |         |         |       |
| Magnetventil/Magnetic valve/Electrovanne               |         |         |       |
| Widerstand/Resistance/Résistance                       | W       |         |       |
| Spannung/Voltage/Tension                               | V       |         |       |