





Mat. – Nr. – Konstante
3740
Gebrauchsanweisung
58 8449 (de)

Montageanweisung
58 8262
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HEZ341000
Backblech emailiert
HEZ341010
Backblech Antihaft
HEZ341670
Backblech (Auszug)
HEZ342000
Universalpfanne
HEZ342010
Universalpfanne
Antihaft
HEZ343000
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ344000
Kombirost
HEZ324000
Einlegerost
HEZ325000
Grillblech 2-teilig
HEZ346000
Glaspfanne


1) 01 4254






Mat. – Nr. – Konstante
3740


Zubehoer:
HEZ6001
Backform
Auslaufsicher
HEZ317000
Pizzaform
HMZ21GB
Glasbraeter
HEZ6000
Metallbraeter
Ecolyse-Set
HEZ329024





Mat. – Nr. – Konstante
3740

- 1) 42 2755
- 2) 42 2747



Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740

