



Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 7710 (de)
58 7711 (it)


Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HEZ331070
Backblech emailliert
HEZ331010
Backblech Antihaft
HEZ332070
Universalpfanne
HEZ332010
Universalpfanne
Antihaft
HEZ333070
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ3340001
Kombirost
HEZ324000
Einlegerost
HEZ325070
Grillblech 2-teilig
HEZ336000
Glaspfanne
HEZ6001
Backform
Auslaufsicher
HEZ317000
Pizzaform










Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740

