





Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 7478 (en)

Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HEZ331070
Backblech emailiert
HEZ331010
Backblech Antihft
HEZ332070
Universalpfanne
HEZ332010
Universalpfanne
Antihft
HEZ333070
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ3340001
Kombirost
HEZ324000
Einlegerost
HEZ325070
Grillblech 2-teilig
HEZ336000
Glaspfanne
HEZ6001
Backform
Auslaufsicher
HEZ317000
Pizzaform









Mat. – Nr. – Konstante
3740

1) 471534
Set
V01



Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740

