


**BOSCH**

EURO-CLASSIC 1000 – WOK2001/02–V01
WOK 2001 – WOK2001GB/02–V02
EURO-CLASSIC 1000 – WOK2001/04–V03
WOK 2001 – WOK2001GB/04–V04

EURO-CLASSIC 1000 – WOK2001/05–V05
WOK 2001 – WOK2001GB/05–V06

WASCHGERÄTE
Waschvollautomaten



1) 2 x pro Gerät



**BOSCH**

EURO-CLASSIC 1000 – WOK2001/02–V01
WOK 2001 – WOK2001GB/02–V02
EURO-CLASSIC 1000 – WOK2001/04–V03
WOK 2001 – WOK2001GB/04–V04

EURO-CLASSIC 1000 – WOK2001/05–V05
WOK 2001 – WOK2001GB/05–V06

WASCHGERÄTE
Waschvollautomaten

