


**BOSCH**

WOK 2030 – WOK2030/02–V01
 WOK 2031 – WOK2031/02–V02
 WOK 2030 – WOK2030/04–V03
 WOK 2031 – WOK2031/04–V04

WOK 2031 – WOK2031/05–V05
 WOK 2030 – WOK2030/05–V06

WASCHGERÄTE
 Waschvollautomaten



Gebrauchsanweisung

52 0769

(D) V01, V03, V06

52 2422

(D) V02, V04, V05

Aufstellanweisung

52 0294

(D)

Programmtabelle

52 1188

(D) V01, V03, V06

52 2093

(D) V02, V04, V05

1) Blende kompl.

35 0476

V01, V03, V06

35 3054

V02, V04, V05

Zubehör:

Bodenbefestigung

WMZ2200

Verlängerung

Zulaufschlauch 2,5 m

WMZ 2380/01

Entkalker


46 0038

**BOSCH**

WOK 2030 – WOK2030/02–V01
 WOK 2031 – WOK2031/02–V02
 WOK 2030 – WOK2030/04–V03
 WOK 2031 – WOK2031/04–V04

WOK 2031 – WOK2031/05–V05
 WOK 2030 – WOK2030/05–V06

WASCHGERÄTE
 Waschvollautomaten



- 1) 2 x pro Gerät
 2) 26 0752
 V01–V04
 26 6722
 V05,V06



**BOSCH**

WOK 2030 – WOK2030/02–V01
WOK 2031 – WOK2031/02–V02
WOK 2030 – WOK2030/04–V03
WOK 2031 – WOK2031/04–V04

WOK 2031 – WOK2031/05–V05
WOK 2030 – WOK2030/05–V06

WASCHGERÄTE
Waschvollautomaten

