






Kullanma kilavuzu
52 3815
(TR)

- 1) 17 1312
- 2) 17 1304
- 3) 17 4106
V01
17 4107
V02
26 8570
V03,V04
48 0020
V05
- 4) 17 1518
V01
26 8286
V02,V03,V04,V05
- 5) 35 4317
V01
35 8291
V02,V03,V04,V05
- 6) 35 5042
V01,V02,V03
35 9732
V04,V05
- 7) 17 1522
V01,V02,V03
18 0735
V04,V05
- 8) 17 1521
V01,V02
17 6128
V03,V04,V05
- 9) 35 9842
V05



- 1) 17 1501
V01
- 2) 17 1321
- 3) 17 1506
- 4) 35 4314
- 5) 35 4164
- 6) 35 4167
V01
35 7912
V02,V03,V04,V05
- 7) 35 4161
V01
35 7913
V02,V03,V04,V05
- 8) 35 5046
V01,V02,V03,V04
36 0398
V05
- 9) 35 5830
V01,V02,V03,V04
36 0406
V05



Pos.	V01	V02, V03, V04, V05	
	Danfoss	Danfoss	
	NL7FT	NL9FT	
1	14 1810	14 1811	
2	16 5570		
3	35 4158		
4	16 3427		
5	26 5327		
6	17 1318		
7	17 1519		
8	17 2776		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör	Danfoss	Danfoss	
Typ/Type/Tip	NL7FT	NL9FT	
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	11.4	12.8	
Widerstand/Resistance/Rezistans Ha/	10.7	8.9	
Hi/aux.	13	12	
Temp.Reyler/Thermostat/Termostat	Elektronisch		
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C		
Valeurs de commutation/Termostat degeri	..aus"/kapama		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı	R134a	*	
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans	Verdampfer	Ablaufrinne	
Widerstand/Resistance/Direnc	Ω		
Leistung/Power/Guc	W	120	20
Ventilador/Blower/Vantilatör	Verdampfer		
Widerstand/Resistance/Rezistans	Ω		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ω		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız