

**BOSCH**

TAT3705/01-V01, weiss
TAT3705CH/01-V02, weiss
TAT3705GB/01-V03, weiss
TAT3713/01-V04, Exklusiv

TAT3720/01-V05, Mosaik
TAT3714/01-V06, Exklusiv
TAT3780/01-V07, Weiss
TAT3783/01-V08, Vanilla

KLEINE HAUSGERÄTE
Toaster

Ident - Nummern - Konstante
3740

51 7144
Gebrauchsanweisung
(D, GB, F, I, NL, DK, N, S, SF,
E, P)

1) 03 1496

