


MCM5000/01 – V01
MCM5010GB/01 – V02
MCM5010/01 – V03
MCM5079/02 – V04

MCM5080/02 – V05
MCM5081/02 – V06
MCM5081GB/02 – V07
MCM5000/02 – V08


MCM5010/02 – V09
MCM5010GB/02 – V10

KLEINE HAUSGERÄTE
Küchenmaschinen




Mat. – Nr. – Konstante
3740

52 8421
V01–V03
58 3858
V04–V10
Gebrauchsanweisung
(de,en,fr,it,nl,da,
no,sv,fi,es,pt,el,tr,
pl,hu,bg,ru,ar)
58 3859
V04–V07
Rezeptheft
(de,en,fr,it,nl,da,
no,sv,fi,es,pt,el,
tr,pl,hu,bg,ru,ar)
Zubehör:
Pommes–Frites–
Scheibe
MZ 24582
V01–V03
Reibscheibe grob
MZ 24627
V01–V03
Pommes–Frites–
Scheibe
MZ5PS01
V04–V10
Reibscheibe grob
MZ5RS01
V04–V10
Julienne Scheibe
MZ5JS01
V04–V10
Schneid–Raspel–
Wendescheibe
MZ5KP01
V04–V10




41 8142

36 1735
V01–V03



48 9136
V04–V10




48 9137
V04–V10


36 1736



48 1125




48 1124




48 1126




48 1090



26 0840
V01–V03
08 3576
V04–V10




26 0841
V01–V03
08 3577
V04–V10



361724
V02,V03,
V06,V07
V09,V10

48 1116
V01–V03,
V05–V10

48 1117
V01–V03,
V05–V10




26 3816
V01–V03,
V05–V10

18 2736
V01–V03,
V05–V10

48 9138
V01–V03
V05–V10

48 1122
V01–V03,
V05–V10

48 1118
V01–V03,
V05–V10



18 4562
V01–V03,
V05–V10

Mat. – Nr. – Konstante
3740