


**BOSCH**

HEN200SEU/01-V01, braun
 HEN202SEU/01-V02, weiß
 HEN206SEU/01-V03, graphit

HEN200SEU/02-V04, braun
 HEN202SEU/02-V05, weiß
 HEN206SEU/02-V06, graphit

HERDE
 Einbaubacköfen



Ident – Nummern – Konstante
 3740

Gebrauchsanweisung
 51 9257
 (D, GB, F, NL, I, E, DK,
 GR, N, SF, S, P)


Montageanweisung
 51 9059
 (D, GB, F, NL, I, E, DK,
 GR, N, SF, S, P)

**BOSCH**

HEN200SEU/01-V01, braun
HEN202SEU/01-V02, weiß
HEN206SEU/01-V03, graphit

HEN200SEU/02-V04, braun
HEN202SEU/02-V05, weiß
HEN206SEU/02-V06, graphit

HERDE
Einbaubacköfen



**BOSCH**

HEN200SEU/01-V01, braun
HEN202SEU/01-V02, weiß
HEN206SEU/01-V03, graphit

HEN200SEU/02-V04, braun
HEN202SEU/02-V05, weiß
HEN206SEU/02-V06, graphit

HERDE
Einbaubacköfen

Ident – Nummern – Konstante
3740

