




Gebrauchsanweisung
51 4839
(D)

Aufstellanweisung
51 4934
(D,I,SF,N,S)
51 4750
(D,GB,F,I,NL,E)

Programmtabelle
51 4753
(NL,F,E,GB)
51 4754
(D,I,SF,N,S)

1) 28 2622
Blende kompl.

2) 03 2288
3) 05 9694
4) 05 9344 1)


Zubehör:


Bodenbefestigung
CZ 1106


Wäsche-Top
CZ 11330

Verlängerung
Zulaufschlauch 2,5 m
CZ 11350

Entkalker
46 0038







28 8964

