


Thermador®	WD24UW	– V01, white	WD24ZS/01	– V06, stainless	COOKING Warming Drawers
	WD24UW/01	– V02, white	WD24US	– V07, stainless	
	WD24UB	– V03, black	WD24ZP	– V08, pro	
	WD24UB/01	– V04, black	WD24ZP/01	– V09, pro	
	WD24ZS	– V05, stainless			





Thermador®	WD24UW	– V01, white	WD24ZS/01	– V06, stainless	COOKING
	WD24UW/01	– V02, white	WD24US	– V07, stainless	Warming Drawers
	WD24UB	– V03, black	WD24ZP	– V08, pro	
	WD24UB/01	– V04, black	WD24ZP/01	– V09, pro	
	WD24ZS	– V05, stainless			

Page/Item	Part No.	Image	Part Description
01 01	41 4389	HANDLE	HANDLE, WD24U WHT
01 01	V01,V02, 41 4388	HANDLE	HANDLE, WD24U BLK
01 01	V03,V04,V07, 18 6898	HANDLE-DOOR	HANDLE STAINLESS/TR
01 01	V05,V06, 23 8524	HANDLE	ASSEMBLED PRO HANDLE, 24"
01 02	V08,V09, 41 4684	SPACER	SPACER, HANDLE
01 03	14 3069	SUPPORT	GLASS SUPT ASSY WD24UW WH
01 03	V01,V02, 14 3068	SUPPORT	GLASS SUPT ASSY WD24UB BL
01 03	V03,V04,V05,V06,V07, 48 7026	SUPPORT	GLASS SUPT ASSY WD24US S/
01 04	V08,V09, 18 9343	LENS	LENS, RED PILOT LONG
01 05	18 9348	PLATE	NAME PLATE, THERMADOR BLA
01 06	V08,V09, 18 9417	SCREW	SCREW, 6 X 1/2 " PH
01 07	14 3067	DRAWER	DRAWER, FRONT WHT WD24NW
01 07	V01,V02, 23 8511	PANEL	DRAWER FRONT, BLACK WD24X
01 08	V03,V04,V05,V06,V07,V08,V09, 48 4857	NUT	CORD, POWER
01 09	18 9250	SCREW	SCREW #8A X 3/8 PH PN HD
01 10	23 8500	BOX	CSN, BACK WD24
01 11	48 6755	INSTALLATION SET	KIT-WD24Q WRAP
01 12	36 7217	INSULATING PART	FIBERGLASS INSULATION 24"
01 14	48 5295	SLEEVE	GASKET, 4.666FT (WD24Q)
01 15	23 8499	BOX	CAN, HALF WD24Q
01 16	23 8503	FRAME	FRAME, FRONT WD24
01 18	18 9440	KNOB	KNOB, MOIST / DRY
01 19	23 8854	DRAWER	DRAWER/SLIDE ASSY WD24Q
01 21	41 4705	SCREW	SCREW 6X3/8 PH PN HD TYPE
* 01 24	18 9342	CLIP	CLIP, LENS
* 01 25	18 9455	LENS	PILOT LENS
* 01 26	41 1506	SCREW	SCREW 7X1/2 PH PL HD BLAC

* Not illustrated

Thermador®	WD24UW	– V01, white	WD24ZS/01	– V06, stainless	COOKING Warming Drawers
	WD24UW/01	– V02, white	WD24US	– V07, stainless	
	WD24UB	– V03, black	WD24ZP	– V08, pro	
	WD24UB/01	– V04, black	WD24ZP/01	– V09, pro	
	WD24ZS	– V05, stainless			



Thermador®	WD24UW	– V01, white	WD24ZS/01	– V06, stainless	COOKING
	WD24UW/01	– V02, white	WD24US	– V07, stainless	Warming Drawers
	WD24UB	– V03, black	WD24ZP	– V08, pro	
	WD24UB/01	– V04, black	WD24ZP/01	– V09, pro	
	WD24ZS	– V05, stainless			

Page/Item	Part No.	Image	Part Description
03 01	23 8505	HEATER-ELEMENT	ELEMENT, HEATING
03 02	18 9244	SCREW	SCREW, 6–32x5/16 PH TR NK
03 03	41 4378	KNOB	KNOB, THERMOSTAT WD24N,Q/
03 04	18 9432	SWITCH	SWITCH, ON/OFF
03 05	18 9423	LAMP	PILOT LIGHT
03 06	18 9433	SCREW	SCREW #4–40 X 5/8 PH
03 07	18 9450	BRACKET	BRACKET, MOUNTING
03 09	18 9429	BRACKET	BRACKET, ON / OFF SWITCH
03 10	18 9427	BRACKET	BRACKET, THERMOSTAT
03 11	18 9345	SCREW	SCREW, 8x1/2 PH TR HD A N
03 12	18 9418	CONTROL UNIT	THERMOSTAT ASSEMBLY WDXX
03 13	18 9431	SCREW	SCREW, 8–32 X 1 PAN HEAD
03 14	23 8520	GRID	RACK, WIRE 24"
03 15	18 9435	SCREW	SCREW, 6–32 X 3/16
03 16	18 9346	NUT	HEX NUT #8 X 32 KEPS
03 17	36 7216	SLIDE	DRAWER SLIDE, WD
03 20	36 7225	RAIL	RAIL, DRAWER SLIDE
* 03 25	18 9450	BRACKET	BRACKET, MOUNTING
40 01	SH-30/0024E		WIRING DIAGRAM
50 01	RH30006E	Repair Instruction	

* Not illustrated