





Gebrauchsanweisung
52 2288
(es,pt,fr,en,de,nl,el,it)

1) 21 4727
V01
21 4728
V02
21 4729
V03
21 4730
V04
2) 16 9876



Düsensatz Für
 Erdgas G20
 16 9802
 18mbar

Flüssigas G30
 16 9779
 28mbar

Stadtgas G110
 18 0831
 110 mbar