








07 4445
V01
09 6325
V02





09 5374




Gebrauchsanweisung
51 7443
Montageanleitung
52 1679

1) 15 0692



1) 35 0986



Pos.	Danfoss		
	TLES 7 K		
1	14 1239		
2	15 1055		
3	15 1919		
4	15 1918		
5	15 1072		
6	15 1053		
7			
8			
9			
10			
11			
12			

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES			
Verdichter/Compressor/Compresseur		Danfoss	Danfoss
Typ/Type		TLES 7 K	TLS 7 K
Förderleistung/Delivery/Débit	l/h	1170	1170
Anlaufstrom/Starting current/Cour de démarrage	A	7,6	8,9
Widerstand/Resistance/Résistance	Ha/main/prin. Ω	16,5	16,0
	Hi/aux Ω	16,9	17,0
Temp.-Regler/Thermostat		Ranco	
Typ/Type		K59	
Reglerstellung/Position		kalt	warm
Schaltwerte/Switching values/	„ein“ $^{\circ}\text{C}$	+5	+5
Valeurs de commutation	„aus“	-28	-17
(„abtauen“ od.)	„alarm“		
Füllmenge/Fill.quantity/Charge	g	28 / R600a	
Anschlußwert/Conn.load/Puiss. connectée	W	90	
Heizung/Heater/Chauffage			
Widerstand/Resistance/Résistance	Ω		
Leistung/Power/Puissance	W		
Ventilator/Blower/Ventilateur		MES F61-10	
Widerstand/Resistance/Résistance	Ω	680	
Schaltuhr/Timer/Minuterie de contact			
Widerstand/Resistance/Résistance	Ω		
Magnetventil/Magnetic valve/Electrovanne			
Widerstand/Resistance/Résistance	Ω		
Spannung/Voltage/Tension	V		