







Libro de instrucciones
51 7577
(E)

1) 20 9040








* Conj. tornill. tambor
05 9132

1) 14 1162
2/12p.
V01, V02, V03
14 1161
2/16p.
V04

2) 05 9471
12,5μF
V01, V02, V03
08 8672
14 μF
V04



1) 28 7984