


**BOSCH**

SMS2042EU/01-EU1, weiss
 SMS2042EU/08-EU2, weiss
 SMS2042EE/08-E1, weiss

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740




51 4136
Gebrauchsanweisung
 (D,F,GB,I,NL)
 51 3779
Montageanweisung
 (D,F,GB,I,NL,DK,
 E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944 Set
- 6) —
- 7) —
- 8) —
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set

**BOSCH**

SMS2042EU/01-EU1, weiss
 SMS2042EU/08-EU2, weiss
 SMS2042EE/08-E1, weiss

GESCHIRRSPÜLGERÄTE
 Standgeräte




**BOSCH**

SMS2042EU/01–EU1, weiss
 SMS2042EU/08–EU2, weiss
 SMS2042EE/08–E1, weiss

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740



- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6970
- 7) 04 3889

**BOSCH**

SMS2042EU/01–EU1, weiss
SMS2042EU/08–EU2, weiss
SMS2042EE/08–E1, weiss

GESCHIRRSPÜLGERÄTE
Standgeräte

Ident – Nummern – Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247

