






Thermador®	WD30XW – V01,	white	WD30XW/01 – V02,	white	COOKING Warming Drawers
	WD30XB – V03,	black	WD30XB/01 – V04,	black	
	WD30XS – V05,	stainless			
	WD30ZS – V06,	stainless	WD30ZS/01 – V07,	stainless	
	WD30ZP – V08,	stainless	WD30ZP/01 – V09,	stainless	

Page/Item	Part No.	Image	Part Discription
01 01	41 4393	HANDLE	HANDLE, DOOR 30" WHT
01 01	V01,V02, 48 6868	HANDLE	HANDLE, DOOR 30" BLK
01 01	V03,V04,V05, 43 2842	HANDLE-DOOR	HANDLE, DOOR S30"S/S
01 01	V06,V07, 48 6001	HANDLE	ASSY, PRO HANDLE/ENDCAPS
01 02	V08,V09, 41 4817	SPACER	SPACER, DOOR HANDLE
01 03	V01,V02,V03,V04,V05,V06,V07, 14 3076	SUPPORT	GLASS SUPT ASSY WD30X BLK
01 03	V01,V02, 14 3075	SUPPORT	GLASS SUPT ASSY WD30X BLK
01 03	V03,V04, 14 3077	SUPPORT	GLASS SUPT ASSY WD30X S/S
01 03	V05,V06,V07, 36 7227	SUPPORT	GLASS SUPPORT ASSEMBLY WD
01 05	V08,V09, 18 9348	PLATE	NAME PLATE, THERMADOR BLA
01 06	V05,V06,V07,V08,V09, 18 9417	SCREW	SCREW, 6 X 1/2 " PH
01 07	14 2560	DRAWER	DRAWER, FRONT WD30X WHT
01 07	V01,V02, 23 8513	PANEL	DRAWER FRONT BLACK, WD30X
01 08	V03,V04,V05,V06,V07,V08,V09, 48 4857	NUT	CORD, POWER
01 09	18 9250	SCREW	SCREW #8A X 3/8 PH PN HD
01 10	23 8501	BOX	CAN, BACK WD 27
01 11	48 7027	Foil	WRAP, HALF WD27Q
01 12	36 7218	INSULATING PART	FIBERGLASS CUT 27"
01 13	18 9437	PLATE	MOIST DRY W/A
01 14	48 5294	SLEEVE	GASKET, 5.312 FT (WD27Q)
01 15	23 8498	BOX	CAN, HALF WD27Q
01 16	23 8502	FRAME	FRAME FRONT WD30
01 18	18 9440	KNOB	KNOB, MOIST / DRY
01 19	23 8510	DRAWER	DRAWER, WD27X
01 21	41 4705	SCREW	SCREW 6X3/8 PH PN HD TYPE
* 01 24	18 9342	CLIP	CLIP, LENS
* 01 25	18 9455	LENS	PILOT LENS
* 01 26	41 1506	SCREW	SCREW 7X1/2 PH PL HD BLAC

* Not illustrated

Thermador®	WD30XW – V01,	white	WD30XW/01 – V02,	white	COOKING Warming Drawers
	WD30XB – V03,	black	WD30XB/01 – V04,	black	
	WD30XS – V05,	stainless			
	WD30ZS – V06,	stainless	WD30ZS/01 – V07,	stainless	
	WD30ZP – V08,	stainless	WD30ZP/01 – V09,	stainless	



Thermador®	WD30XW – V01,	white	WD30XW/01 – V02,	white	COOKING Warming Drawers
	WD30XB – V03,	black	WD30XB/01 – V04,	black	
	WD30XS – V05,	stainless			
	WD30ZS – V06,	stainless	WD30ZS/01 – V07,	stainless	
	WD30ZP – V08,	stainless	WD30ZP/01 – V09,	stainless	

Page/Item	Part No.	Image	Part Description
03 01	23 8504	HEATER-ELEMENT	ELEMENT
03 02	18 9244	SCREW	SCREW, 6-32x5/16 PH TR NK
03 03	41 4378	KNOB	KNOB, THERMOSTAT WD24N,Q/
03 04	18 9432	SWITCH	SWITCH, ON/OFF
03 05	18 9423	LAMP	PILOT LIGHT
03 06	18 9433	SCREW	SCREW #4-40 X 5/8 PH
03 07	18 9450	BRACKET	BRACKET, MOUNTING
03 08	18 9430	COVER	COVER, THERMOSTAT
03 09	18 9429	BRACKET	BRACKET, ON / OFF SWITCH
03 10	18 9427	BRACKET	BRACKET, THERMOSTAT
03 11	18 9345	SCREW	SCREW, 8x1/2 PH TR HD A N
03 12	18 9418	CONTROL UNIT	THERMOSTAT ASSEMBLY WDXX
03 13	18 9431	SCREW	SCREW, 8-32 X 1 PAN HEAD
03 14	23 8521	GRID	RACK WIRE 27"
03 15	18 9435	SCREW	SCREW, 6-32 X 3/16
03 16	18 9346	NUT	HEX NUT #8 X 32 KEPS
03 20	36 7225	RAIL	RAIL, DRAWER SLIDE
03 25	18 9450	BRACKET	BRACKET, MOUNTING
* 40 01	SH-30/0024E	WIRING DIAGRAM	
* 50 01	RH30007E	Repair Instruction	

* Not illustrated