




- 2) 09 6507
V01
(D)
09 6515
(I)
09 6516
(P)
09 6517
(E)
09 6518
(D)
09 6587
(F)
09 6586
(GB)
09 6588
(NL)
- 3) 09 6652
(D)
09 6654
(I)
09 6655
(P)
09 6656
(E)
09 6717
(GB)
09 6653
(F)
09 6718
(NL)

Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

51 7936

(D)

51 8057

(D,E,I)

51 8090

(NL,F,GB)

Aufstellanweisung

51 8126

(D)

51 8127

(I,P,E)

51 813

(NL,F,GB)

Programmtabelle

51 7937

(D)

51 7983

(E)

51 7984

(1)

51 7985

(P)

51 8022

(GB)

51 8021

(F)

51 8020

(NL)

1) Blende

28 9894

(D)

29 0444


(NL)

**BOSCH**

WFF 2030 – WFF2030/01–V01
 WFF 2030 – WFF2030IE/01–V02
 WFF 2030 – WFF2030FG/01–V03
 WFF 2030 – WFF2030NL/01–V04

WFF 2030 – WFF2030DD/01–V05

WASCHGERÄTE
 Waschvollautomaten



Ident – Nummern – Konstante
 3740

1) 29 7299
 Set

Zubehör:

Verbindungssatz für
 Wasch/Trockensäule
 WTZ1120

Verlängerung
 Arbeitsplatte
 WMZ2320

Unterbaubehör
 WMZ2340

Bodenbefestigung
 WMZ2200

**BOSCH**


WFF 2030 – WFF2030/01–V01
 WFF 2030 – WFF2030IE/01–V02
 WFF 2030 – WFF2030FG/01–V03
 WFF 2030 – WFF2030NL/01–V04


WFF 2030 – WFF2030DD/01–V05

WASCHGERÄTE
 Waschvollautomaten

Ident – Nummern – Konstante
 3740

1) 15 4431
 Kabelbaum NTC
 16 0957





**BOSCH**

WFF 2030 – WFF2030/01–V01
WFF 2030 – WFF2030IE/01–V02
WFF 2030 – WFF2030FG/01–V03
WFF 2030 – WFF2030NL/01–V04

WFF 2030 – WFF2030DD/01–V05

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740

