







Libro de instrucciones
51 9303
(es,pt)


1) 06 9817
V01
06 6077
V02, V03

2) 06 9821
V01
06 6077
V02, V03









1) 03 3793

Cjtos transformación:
Gas Butano
15 3164
Gas Natural
15 3165
Gas Ciudad
15 3166