

Libro de instrucciones
51 6561
(E)

1) Gas
03 8702
V01
03 8695
V02
Eléctrico
03 8701
V01
03 8694
V02


2) 06 7268
V01
06 7267
V02

3) 03 8698
V01
03 8691
V02


4) 03 4304
V01
03 7001
V02


5) 03 6087

6) 03 4304
V01
03 7001
V02



- 1) 06 7514
- 2) 03 9099
- 3) 03 9227
- 4) 03 8403
- 5) 06 7855
- 6) 06 7852





Cable de entrada
27 5796

