




Gebrauchsanweisung
 51 6973
 (D,F,GB,I,NL,E)
 V01,V02,V03,V05,V06
 51 9779
 (NL)
 V04

Montageanleitung
 51 6089
 (D,GB,F,I,NL,E)


Kochbuch
 51 5729
 (D)
 V01
 51 5849
 (NL)
 V02,V04
 51 5853
 (F)
 V03
 51 6252
 (GB)
 V05

Zubehör:


Alu-Backblech
 HZ 8055

Glaspfanne
 HZ 8056


Glasbräter
 HZ 9150



- 1) 03 0671
Stössel
- 2) 03 0813
Arretierstift



- 1) 11 4538
Backblech
V01, V02, V03, V05,
V06
 - 2) 11 4539
Rost
 - 3) 11 4537
Glasschale
 - 4) 27 0323
V01, V02 V03, V04, V06
27 1620
V05
- 02 8732
Anschlag für Backblech
V01, V02, V03, V05, V06



- 1) 06 6760
- 2) 06 6448
- V01, V02, V03
- 06 5353
- V04, V05
- 05 8742
- V06

