





Gebrauchsanweisung  
58 4558  
(de,fr,nl,it)

Montageanleitung  
51 7991  
(de,en,fr,nl,it,es,pt,el)

Kochbuch  
58 4514


Zubehör:

Back- u. Bratrost-  
engmasching  
Z1440X0  
Back- u. Bratrost  
gekröpft  
Z1430X0  
Backblech Alu  
Z1330X0  
Backblech Email  
Z1340X2  
Universalpfanne u.  
Bratrost  
Z1230X2




- 1) 41 8604
- 2) 16 8588
- 3) 18 3036
- 4) 18 3035





- 1) 17 2765
- 2) 17 2646
- 3) 18 2612
- 4) 18 2613



- 1) 41 8562
- 2) 15 5033
- 3) 48 3856