




Gebrauchsanweisung  
52 0869  
(D)  
52 0541  
(GB,F,NL,I,E,GR)


Montageanleitung  
51 7955  
(D,GB,F,NL,I,E,GR)

Kochbuch  
52 2909 – (D)


1) 02 5876

Zubehör:


Universalpfanne  
 u. Bratrost  
 Z1230X0  
 Backblech, Alu  
 Z1330X0  
 Backblech Email  
 Z1340X0  
 Back- und Bratrost  
 gekröpft  
 Z1470X0  
 Bratenblech  
 Z1510X1  
 Brotbackstein  
 Z1910X0  
 Einzelteleskop-  
 auszugsschiene  
 Z1731X0  
 Adapter MEGA  
 Z9600X0  
 Reinigerschwamm  
 15 5067



- 1) 15 9900
- 2) 05 4816
- 3) 15 9899



- 1) 15 4762
- 2) 15 4763
- 3) 02 6593



- 2) 09 6825  
kompl.
- 3) 06 9709
- 5) 15 5033