







Libro de instrucciones
51 9790
(E)







- 1) 06 9605
- 2) 06 7297
- 3) 06 8344
- 4) 03 2584
- 5) 09 3558
(1200 r.p.m.)
V03

* Conj. tornill. tambor
05 9132

