






Libro de instrucciones
51 5460
(E, GB, P, F, D)

- 1) 03 1989
- 2) 03 1987
- 3) 03 1988
- 4) 03 5731
- 5) 03 3055
- 6) 06 6770
- 7) 06 7467





Pos.	MATSUSHITA SO75LKAA	MATSUSHITA SO75LKAA
1	14 0582	14 0582
2		
3	06 4055	06 4055
4		
5		
6		
7		
8	28 0162	
9	05 0166	05 0166
10		
11	08 8868	
12		
13		

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo	MATSUSH. SO75LKAA	MATSUSH. SO75LKAA
Förderleistung/Delivery/Debit/Aspiración l/h		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	5,69	5,69
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	24,4	24,4
Hi/aux.	39,8	39,8

Temp.Reyler/Thermostat/Termostato Typ/Type/Tipo	DANFOS 077B62	RANCO K54 L1924
Reglerstellung/Position/Conexión	MIN.-MAX	MIN.-MAX
Schaltwerte/Switching values/	+6°	-14° -24°
Valeurs de commutation/Desconex.	-13° -28°	-21° -31°
(..abtaven' od)	..alarm'	-15

Füllmenge/Fill. quantity/Charge/Carga R12	g	70	145
---	---	----	-----

Anschlußwert/Comm. load/puiss. Connect./Potenc.	W	91	91
---	---	----	----

Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia	Ohm		
Leistung/Power/Puissance/Potencia	W		

Ventilator/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Ohm		
---	-----	--	--

Magnetventil/Magnetic valve/Electrovanne/Electrovalvula Widerstand/Resistance/Resistencia	Ohm		
Spannung/Volare/Tension/Tensión	V		

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador			
--	--	--	--