





Ident – Nummern – Konstante
3740Gebrauchsanweisung
52 8832
(es,pt)



- 1) 17 2346
2) 17 2342





Ident - Nummern - Konstante
3740

- 1) 18 2307
- 2) 35 9993
- 3) 35 9996
- 4) 35 9997
- 5) 35 9998

Erdgas G20
18 4373
Flüssigas G30
18 4581