







Libro de instrucciones
51 6719
(E)

1) 20 8978
V01,V02
20 8976
V03,V04
20 8974
V05,V06
20 8975
V07,V08
20 8977
V09,V10
20 8973
V11,V12







* Conj. tornill. tambor
05 9132

1) 14 1161
V07,V09,V11
V08,V10,V12
14 1162
V01,V02,V03
V04,V05,V06

2) 08 8672
V07,V09,V11
V08,V10,V12
05 9471
V01,V02,V03
V04,V05,V06

