






Page/Item	Part No.	Image	Part Description
01 01	41 1036	SPRING	SPRING, CATCH
01 02	41 7550	SPRING	Spring, catch
01 03	43 4305	FIXING KIT	Kit,control Panel Plate &
01 04	41 3561	BRACKET	BRACKET, DISPLAY
01 05	36 8441	PANEL-FACIA	SKIN, CONTROL PNL Bla C30
	V01,		
01 05	36 8443	PANEL-FACIA	SKIN, CONTROL PNL S/S
	V02,		
01 05	36 8442	PANEL-FACIA	SKIN, CONTROL PNL WHT
	V03,		
01 08	41 3571	BRACKET	BRACKET, CTRL PNL GLASS
01 09	48 6915	DISPLAY	CONTROL, DISPLAY PCB DBL
01 10	14 2859	GLASS PANEL	GLASS, TOUCH PNL W/FILTER
01 11	41 5422	SWITCH	SWITCH, SHUTTER INTERLOCK
01 12	41 3599	PLATE	PLATE, UPPER LATCH BLK
01 13	41 4633	FUSE-THERMAL	HTC M2
01 14	41 8806	LOCK-MECHANICAL	LATCH, DOOR (MICROWAVE)
01 15	41 3118	PLATE	SHIELD, LATCH
01 16	41 1059	DAMPER	BUMPER, DOOR
01 17	43 4305	FIXING KIT	Kit,control Panel Plate &

* Not illustrated




Page/Item	Part No.	Image	Part Description
11 01	36 8445	FRAME	BODY, MID PLENUM 30"
11 02	48 5978	BRACKET	BRACKET, BLWR MTG LOWER
11 03	43 1492	INSTALLATION SET	KIT, BLOWER CROSSFLOW
11 04	48 9102	LOCK-ELECTRICAL	latch assy, motorized
11 05	41 3118	PLATE	SHIELD, LATCH
11 06	36 8285	COVER	COVER, LATCH WIRE MID
11 07	41 3567	DUCT	CHANNEL, MID VENT ASSY
11 08	41 5422	SWITCH	SWITCH, SHUTTER INTERLOCK
11 09	48 6004	INSULATING PART	INSULATION, VENT
11 10	41 1059	DAMPER	BUMPER, DOOR
11 11	41 4633	FUSE-THERMAL	HTC M2
11 12	41 1007	STUD	BALL STUD
11 13	41 7550	SPRING	Spring, catch
11 14	48 6328	PLATE	PLATE, MID LATCH 30"BLK
* 11 15	36 8447	PANEL	PARTITION, MID PLENUM C30

* Not illustrated




Page/Item	Part No.	Image	Part Description
13 02	23 8834	OVEN	MODULE, OVEN CAN C30
13 03	36 8265	REFLECTOR	REFLECTOR
13 05	36 7632	SHELF	RACK, OVEN CM
13 06	48 5998	SUPPORT	SUPPORT, RACK CONVECTION
13 07	48 5982	COVER	COVER, CONVECTION MTR BRK
13 08	41 1220	catalyzer	CATALYST
13 10	36 7654	HEATER-ELEMENT	ELEMENT, BAKE 30" C-OVEN
13 11	36 7647	HEATER-ELEMENT	ELEMENT, BROIL
13 12	36 8281	AIR CHANNEL	BAFFLE, CONVECTION 30" W/
13 14	48 4787	HEATER-ELEMENT	ELEMENT, CONVECTION
13 15	48 5973	BRACKET	BRACKET, COUNTER SUPT LH
13 16	48 5972	BRACKET	BRACKET, COUNTER SUPT RH
13 17	41 4510	HOLDER	SUPPORT, HINGE COUNTER
13 20	48 8763	HOUSING	Enclosure, Element
13 21	41 3564	COVER	COVER, CONCEALED ELEMENT
13 22	41 4512	LAMP HOUSING	LAMP, OVEN
13 23	41 4152	TEMPERATURE SENSOR	THERMAL SENSOR KIT
13 25	41 3573	PLUG	PLUG, PROBE HOLE
13 31	41 4512	LAMP HOUSING	LAMP, OVEN
13 32	41 5813	LAMP-HALOGEN	BULB, HALOGEN 10WATT
* 13 41	41 2840	PLATE	PLATE, COVER REAR SHIELD
* 13 42	48 7018	MOTOR	MOTOR, CONVECTION
* 13 43	48 7019	FAN BLADE	FAN BLADE, CONVECTION
* 13 44	41 3119	NUT	NUT, CONVECTION MOTOR
* 13 45	48 6323	BRACKET	BRACKET, CONVECTION MOTOR
* 13 46	41 3128	SPACER	SPACER,.312ODX1.550LX.214
* 13 47	41 3466	SCREW	SCREW #10x2"PH TRUSS TYPE
13 50	48 8400	SWITCH	SWITCH, SAIL

* Not illustrated



Page/Item	Part No.	Image	Part Description
15 01	47 0538	DOOR–INNER	DOOR, LINER W/STRIKE ASSY
15 02	48 6767	SEAL–DOOR	GASKET, 30" OVEN DOOR KIT
15 05	41 4511	HINGE	HINGE, DOOR 30" (S/S)
15 07	21 9357	GLASS PANEL	GLASS, INNER WINDOW 4MM 2S
15 08	48 6281	BRACKET	BRACKET, GLASS SUPPORT SI
15 09	36 9152	SPACER	SPACER, INNER WINDOW
15 11	48 6262	FRAME	TRIM, DOOR TOP 30" BLK
15 11	48 6262	FRAME	TRIM, DOOR TOP 30" BLK
15 12	41 3565	COVER	ENDCAP, DOOR LH BLK
15 13	41 3566	COVER	ENDCAP, DOOR RH BLK
15 14	36 8286	INSULATING PART	COVER, DR INSULATION 30"B
15 16	21 9116	AIR CHANNEL	BAFFLE, DOOR 30 P–PTD BLK
15 18	23 8758	GLASS PANEL	ASSY, DOOR GLASS C30 BLAC
	V01,		
15 18	23 8760	GLASS PANEL	ASSY, DOOR GLASS C30 S/S
	V02,		
15 18	23 8759	GLASS PANEL	ASSY, DOOR GLASS C30 WHIT
	V03,		
15 26	48 7596	HANDLE	HANDLE, DOOR C30" BLK
	V01, V02,		
15 26	48 7597	HANDLE	HANDLE, DOOR C30" WHT
	V03,		
15 28	41 1060	SPACER	SPACER, HANDLE
15 29	41 2838	LOCK	STRIKE, DOOR (BLK OXIDE)

* Not illustrated




Page/Item	Part No.	Image	Part Description
17 01	48 6269	COVER	COVER, TOP FRONT 30"C
17 02	36 8464	COVER	COVER, TOP LOWER
17 03	48 6300	FRAME	TRIM, TOP 30" C-OVEN
17 04	36 8501	FRAME	TRIM, SIDE DBL C-OVEN
17 05	48 5678	INSULATING-/PROTECTION SL	CONDUIT, FLEX 1/2 X 60
17 06	41 4692	CONNECTION	CONNECTOR, 1/2" x 90DEG
17 07	41 5812	FUSE-THERMAL	PROTECTOR, KNOCKOUT
17 08	41 4693	INSULATING PART	INSULATOR, SLIP-ON
17 09	41 3575	BRACKET	BRACKET, SIDE TRIM SUPPOR
17 10	36 8485	COVER	COVER, BACK DBL 30"
17 13	18 9250	SCREW	SCREW #8A X 3/8 PH PN HD
17 21	21 9355	BASE	BASE ASSY 30"
17 24	36 9986	PANEL-BASE	TRIM, BASE HORIZONTAL 30

* Not illustrated


Page/Item	Part No.	Image	Part Description
* 19 01	41 3579	Cable harness	HARNESS, DOOR LATCH (JET
* 19 02	18 9954	Cable harness	HARNESS, MEAT PROBE
* 19 03	18 9956	Cable harness	HARNESS, MICROWAVE LATCH
* 19 04	58 2234	INSTALLATION INSTRUCTIONS	INSTRUCTIONS, INSTALL OVE
* 19 05	18 9958	Cable harness	HARNESS, CAP-DIODE
* 19 06	41 3580	Cable harness	HARNESS, TRIAC CONTROL
* 19 07	41 3581	Cable harness	HARNESS, DC BRIDGE
* 19 08	18 9959	Cable harness	HARNESS, TUBE COOLING FAN
* 19 10	18 9946	Cable harness	HARNESS, DISPLAY SIGNAL
* 19 11	18 9960	Cable harness	HARNESS, STIRRER
* 19 12	18 9944	Cable harness	HARNESS, KEYPAD POWER
* 19 13	18 9945	Cable harness	HARNESS, KEYPAD SIGNAL
* 19 14	18 9947	Cable harness	HARNESS, COMMUNICATION SI
* 19 15	18 9949	Cable harness	HARNESS, DLB SGL/UPR OVEN
* 19 16	18 9950	Cable harness	HARNESS, DLB LOWER OVEN
* 19 17	18 9961	Cable harness	HARNESS, SGL/UPR OVEN HTC
* 19 18	48 4546	Cable harness	HARNESS, CM MAIN UPPER OV
* 19 19	48 4536	Cable harness	HARNESS, MAIN LOWER OVEN
* 19 20	48 4537	Cable harness	HARNESS, LIGHT DBL OVEN
* 19 21	18 9953	Cable harness	HARNESS, INTERCONNECT TOU
* 19 23	18 9955	Cable harness	HARNESS, LATCH LOWER DOOR
* 19 24	48 4539	Cable harness	HARNESS, HTC & LIGHTS LWR
* 19 26	48 8409	Cable harness	HARNESS, MAIN AIR CM DBL
* 19 28	18 9963	Cable harness	HARNESS, FUSE WIRE
* 19 29	18 9964	Cable harness	HARNESS, STIRRER POWER
* 19 30	18 9962	Cable harness	HARNESS, MAIN AIR SW DBL

* Not illustrated




Page/Item	Part No.	Image	Part Description
03 02	48 7022	MOTOR–FAN	BLOWER, CROSSFLOW TOP COO
03 03	41 4791	MOTOR	MOTOR, STIRRER
03 04	48 6291	BRACKET	BRACKET, STIRRER MOTOR
03 05	48 9459	MAGNETRON	kit,magnetron w/studs and
03 06	43 7517	HOUSING	HOUSING ASSY, WAVE GUIDE
03 07	41 3605	REGULATOR–TEMPERATURE	THERMOSTAT
03 08	48 6294	COVER	COVER, WAVE GD INSULATION
03 09	41 3588	COVER	COVER, WAVE GD INSULATION
03 10	48 7748	MOTOR–AERIAL	ECM & TF ASSEMBLY (MOTOR)
03 11	48 4583	RING	E–RING
03 12	48 5995	BRACKET	BRACKET, CONDUIT
03 13	41 4806	SWITCH	SWITCH, MICRO
03 14	48 6321	LOCK–ELECTRICAL	DOOR SW INTERLOCK ASSY
03 15	36 8833	CASE–BOTTOM	BODY, CONTROL PLENUM W/A
03 16	48 8405	TRANSFORMER	TRANSFORMER, LIGHT
03 17	41 3562	RELAY	RELAY, DOUBLE LINE BREAK
03 18	48 4615	TERMINAL	BLOCK, TERMINAL
03 19	48 6911	PC BOARD ASSEMBLY–MAINS P	CONTROL, POWER RELAY PCB
03 20	41 3607	FUSE	BLOCK, FUSE
03 21	41 3608	FUSE	FUSE
03 22	36 9947	PC BOARD	CONTROL, MICROWAVE PCB
03 23	48 7021	MOTOR–FAN	FAN, TRANSFORMER COOLING
03 24	41 3593	SWITCH	SWITCH, AIR INTERLOCK
03 25	48 6308	BRACKET	BRACKET, TRANSFORMER MTG
03 26	48 6334	BRACKET	BRACKET, TRANSFORMER MTG
03 27	48 7680	BRACKET	BRACKET, CAPACITOR MTG
03 28	41 4647	CAPACITOR	CAPACITOR, MICROWAVE
03 29	36 8493	PLATE	SHIELD, SIDE TRANSFORMER
03 30	48 6335	TRANSFORMER	TRANSFORMER, MICROWAVE
03 31	48 6322	BRACKET	BRACKET, HEAT SINK TRANSF
03 32	36 8866	Radiator–box	HEAT SINK, TRANSFORMER
03 33	36 8493	PLATE	SHIELD, SIDE TRANSFORMER
03 34	36 8488	DEFLECTOR	DEFLECTOR, AIR TRANSFORME
03 35	41 5229	DIODE	DIODE
03 36	36 8489	DEFLECTOR	DEFLECTOR, AIR TRANSFORME
03 37	41 4674	SLEEVE	SLEEVE, SHAFT
03 38	41 3488	WASHER	WASHER 430 SS
03 39	41 1531	PIN	PIN, COTTER 1/16X1
03 40	41 5208	BEARING	BEARING, STIRRER
03 41	41 4675	PLATE	BEARING PLATE ASSY
03 42	48 6303	FAN BLADE	BLADE, STIRRER ASSY
03 43	48 6910	PC BOARD ASSEMBLY–MAINS P	CONTROL, POWER RELAY PCB
03 44	41 4837	DAMPER	PAD, TRANSFORMER MOUNTING
03 45	41 4209	INSTALLATION SET	KIT, LIGHT TRANSFORMER
* 03 46	41 4210	INSTALLATION SET	KIT, COOLING FAN CM OVEN

* Not illustrated




Page/Item	Part No.	Image	Part Description
05 01	23 8835	OVEN	MODULE, OVEN CM
05 02	48 7568	GLASS DISH	STIRRER COVER GLASS (CMT)
05 03	48 8763	HOUSING	Enclosure, Element
05 04	41 3564	COVER	COVER, CONCEALED ELEMENT
05 05	48 6279	LAMP	LAMP LIGHT ASSY
05 06	36 7654	HEATER-ELEMENT	ELEMENT, BAKE 30" C-OVEN
05 07	41 6268	catalyzer	CATALYST
05 08	36 8467	SUPPORT	SUPPORT, RACK (CM)
05 09	48 4613	HEATER-ELEMENT	ELEMENT, BROIL
05 10	48 5982	COVER	COVER, CONVECTION MTR BRK
05 11	36 8281	AIR CHANNEL	BAFFLE, CONVECTION 30" W/
05 12	48 4612	HEATER-ELEMENT	ELEMENT, CONVECTION
05 13	41 2863	SUPPORT	SUPPORT, HINGE COUNTER CM
05 14	36 9989	HINGE-DOOR	KIT, HINGE/AUXILIARY SPRI
05 16	36 8494	COVER	COVER, HINGE POCKET
05 17	36 7632	SHELF	RACK, OVEN CM
05 18	41 3574	COVER	COVER, MEAT PROBE
05 19	41 5318	CONTAINER	RECEPTACLE, MEAT PROBE
05 20	48 8404	SENSOR	SENSOR, THERMAL CM SGL/UP
05 50	48 8400	SWITCH	SWITCH, SAIL

* Not illustrated



Page/Item	Part No.	Image	Part Description
07 01	41 2840	PLATE	PLATE, COVER REAR SHIELD
07 02	48 6795	MOTOR-FAN	CONVECTION FAN ASSY CM OV
07 03	48 7019	FAN BLADE	FAN BLADE, CONVECTION
07 04	41 3119	NUT	NUT, CONVECTION MOTOR
07 05	48 6323	BRACKET	BRACKET, CONVECTION MOTOR
* 07 06	41 3128	SPACER	SPACER,.312ODX1.550LX.214
* 07 07	41 3466	SCREW	SCREW #10x2"PH TRUSS TYPE
07 11	41 3578	LAMP	LAMP ASSY W/TRIMMED HSG
07 12	48 6280	SCREENING	SCREEN, MICROWAVE LIGHT
07 13	48 7599	Glass plate	GLASS, LIGHT
07 14	41 3577	FRAME	BEZEL, MICROWAVE LIGHT
* 07 15	41 1019	SCREW	SCREW, 6-20X3/8 PH FL TYP
07 16	48 6279	LAMP	LAMP LIGHT ASSY

* Not illustrated



Page/Item	Part No.	Image	Part Description
09 01	41 4543	SEAL–DOOR	GASKET, DOOR (CM)
09 02	14 2852	FRAME	LINER, DOOR ASSY CM
09 03	36 9989	HINGE–DOOR	KIT, HINGE/AUXILIARY SPRI
09 04	48 6971	GLASS PANEL	GLASS, INNER WINDOW
09 05	23 8878	GLASS PANEL	GLASS, CERAMIC
09 06	41 4673	SPACER	SPACER, GLASS (CM)
09 07	36 8865	Shield	PERFORATED STEEL, GLASS P
09 08	36 8459	COVER	COVER, DOOR INSULATION
09 09	48 6290	AIR CHANNEL	BAFFLE, DOOR (CM)
09 10	14 2855	DOOR	GLASS, DOOR PANEL ASY CM3
	V01,		
09 10	23 8764	DOOR	GLASS, DOOR PANEL ASY CM3
	V02,		
09 10	14 2856	DOOR	GLASS, DOOR PANEL ASY CM3
	V03,		
09 13	48 7596	HANDLE	HANDLE, DOOR C30" BLK
	V01,V02,		
09 13	48 7597	HANDLE	HANDLE, DOOR C30" WHT
	V03,		
09 15	48 6319	ACTUATOR	ACTUATOR ARM ASSY
09 16	41 3565	COVER	ENDCAP, DOOR LH BLK
09 17	41 3566	COVER	ENDCAP, DOOR RH BLK
09 18	48 6262	FRAME	TRIM, DOOR TOP 30" BLK
09 19	41 1060	SPACER	SPACER, HANDLE
09 20	48 6281	BRACKET	BRACKET, GLASS SUPPORT SI
* 09 21	41 2838	LOCK	STRIKE, DOOR (BLK OXIDE)

* Not illustrated