




Mat. – Nr. – Konstante

3740

Gebrauchsanweisung

58 7709 (de)

Montageanweisung

58 6500

(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:

HEZ331070

Backblech emailiert

HEZ331010

Backblech Antihalt

HEZ332070

Universalpfanne

HEZ332010

Universalpfanne

Antihalt

HEZ333070

Profipfanne

HEZ333001

Deckel f. Profipfanne

HEZ3340001

Kombirost

HEZ324000

Einlegerost

HEZ325070

Grillblech 2-teilig

HEZ336000

Glaspfanne

HEZ6001


Backform


Auslaufsicher


HEZ317000

Pizzaform










Mat. – Nr. – Konstante
3740
1) 42 2707



Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740

