


**BOSCH**

MUM4420/00-V01 ab FD 7005
 MUM4423/01-V02
 MUM4420GB/01-V03
 MUM4421/01-V04

MUM4420/02-V05
 MUM4421/02-V06
 MUM4421/03-V07

KLEINE HAUSGERÄTE
 Küchenmaschinen



Mat. - Nr. - Konstante
 3740

Gebrauchsanweisung
 51 3415
 V01-V06
 51 9301
 V07
 (D,GB,F,NL,DK,N,
 S,SF,E)

Zubehör:
 Mixer-Aufsatz-Glas
 MUZ4MX3

Multi-Mixer
 MUZ4MM1
 MUZ4MM3

Fleischwolf
 MUZ4FW1

Zitruspresse
 MUZ4ZP1

Getridemühle
 Stahlmahlwerk
 MUZ4GM1
 MUZ4GM3

Getridemühle
 Steinmahlwerk
 MUZ4GM2

Mixer-Aufsatz-Kunststoff
 MUZ4MX2

Pommes-Frites-Scheibe
 MUZ4PS1


Reibescheibe Grob
 MUZ4RS1

**BOSCH**

MUM4420/00-V01 ab FD 7005
MUM4423/01-V02
MUM4420GB/01-V03
MUM4421/01-V04

MUM4420/02-V05
MUM4421/02-V06
MUM4421/03-V07

KLEINE HAUSGERÄTE
Küchenmaschinen



Mat. - Nr. - Konstante
3740

Antriebseinheit
kompl.

08 6063
V01-V04

095514
V05, V06

48 1736
V07

Getriebefett
31 0056

Rezeptheft
51 5191
(D)

1) 02 9465
Satz
V01-V06
16 0691
V07

2) 03 2911
Satz




BOSCH

MUM4420/00-V01 ab FD 7005
MUM4423/01-V02
MUM4420GB/01-V03
MUM4421/01-V04

MUM4420/02-V05
MUM4421/02-V06
MUM4421/03-V07

KLEINE HAUSGERÄTE
Küchenmaschinen

Mat. – Nr. – Konstante
3740





BOSCH

MUM4420/00-V01 ab FD 7005
MUM4423/01-V02
MUM4420GB/01-V03
MUM4421/01-V04

MUM4420/02-V05
MUM4421/02-V06
MUM4421/03-V07

KLEINE HAUSGERÄTE
Küchenmaschinen

Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

51 5188
(de,en,fr,it,nl,da,no,sv,
fi,es)

