




Gebrauchsanweisung
52 1756
(GB,RK)

Montageanweisung
52 1727
(GB,RK)


Schablone
52 0612

1) 02 5054
2) 02 3898
3) 01 5647


Erdgas E 20 mbar
16 7268


Flüssiggas 50 mbar
16 7269

Flüssiggas 30mbar(Rk)
17 0058



- 1) 16 8523
- 2) 16 5655
- 3) 16 5656





- 1) 09 6826
- 2) 26 4734
kompl.
- 3) 16 0916
- 4) 16 6960
- 5) 16 6963
- 6) 02 4443
- 7) 15 0887
- 8) 16 6968