


**BOSCH**

WFM 4030–WFM4030/01–D1
 WFM 4030–WFM4030DC/01–DC1
 WFM 4030–WFM4030SI/01–SI1
 WFM 4030–WFM4030FG/01–FG1

WASCHGERÄTE
 Waschvollautomaten



Ident – Nummern – Konstante
 3740

Gebrauchsanweisung

51 6828
 (D,NL,F,E,GB,P)
 51 6632
 (D,I,SF,S,N)
 51 6631
 (D,F,I,S,DK)

Aufstellanweisung

51 6545
 (D,NL,F,E,GB,I,P)
 51 6568
 (D,F,I,S,DK)
 51 6569
 (D,I,SF,S,N)

Programmtabelle

51 6543
 (D,GB)
 51 6556
 (NL,F,I,E)
 51 6583
 (S,DK,N,SF)
 51 6544
 (P)

1) Blende kompl.

28 5418

(D)

28 5419

Symbole

2) 09 4278

15 5272

Triac–Motorleistung

46 0038
 Entkalker

**BOSCH**

WFM 4030-WFM4030/01-D1
 WFM 4030-WFM4030DC/01-DC1
 WFM 4030-WFM4030SI/01-SI1
 WFM 4030-WFM4030FG/01-FG1

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740

1) 08 8487
 2500 W
 08 8489
 1900/600 W

